

Teleport-R

IrDA EVA DTS readouts from the Televend Box

With Teleport-R your VMS can **read EVA DTS data from the Televend Box** as a Master. Machine fillers finish IrDA EVA DTS readouts by pairing their Televend Box with the handheld computer. One Teleport-R is used per Televend Box.



Connecting process with a handheld computer:



1

Power off the vending machine



2

Plug in the Teleport-R to the Televend Box using a CA1704U cable



3

Turn on the power and press the service button on the Televend Box



4

Pair the Teleport-R with the IrDa reciever on the handheld computer to read EVA DTS data



5

Power off the vending machine before unplugging the Teleport-R

General specifications

- 🔌 Dimensions:
65 x 30 x 15 mm
- 🔌 Temperature range in vending machine:
-20°C to +55 °C
- 🔌 Humidity in vending machine:
Up to 90% RH non-condensing

Infrared communication

- 🔌 IrDA compatible
- 🔌 Supported baud rates: 2400, 4800, 9600, 19200, 38400, 57600, 115200
- 🔌 Infrared spectrums receive/transmit
850-900nm
- 🔌 Eye-safe operation with limited optical power